




digital wood joints



Survey Board Joints

Corner Joints

To open a file of the kind you need, just press the name of the appropriate folder (e. g. → DXF.10).

Name of the joint:

Name of file: in folder:

← Finger Tenons

F_002 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA_CAD Part 1 → MBA_SIM Part 1
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0

← Lapped Finger Tenons

F_003 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA_CAD Part 1 → MBA_SIM Part 1
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA_CAD Part 2 → MBA_SIM Part 2

← Secret Finger Tenons

F_007 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA_CAD Part 1 → MBA_SIM Part 1
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0

← Fingertip Tenons

F_001 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA_CAD Part 1 → MBA_SIM Part 1
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0

← Lapped Fingertip Tenons

F_004 → DXF.10 – 2D → MicroStation → Velum 2.7 → Iges 5 → MBA_CAD Part 1 → MBA_SIM Part 1
→ DXF.12 – 3D → Minicad 7.0 → Velum 4.0 → MBA_CAD Part 2 → MBA_SIM Part 2





digital wood joints

Survey Board Joints

Corner Joints

← Secret Fingertip Tenons	F_006	→ DXF.10 – 2D → DXF.12 – 3D	→ MicroStation → Minicad 7.0	→ Velum 2.7 → Velum 4.0	→ Iges 5	→ MBA_CAD Part 1	→ MBA_SIM Part 1
← Fingertip Tenons with Key	F_005	→ DXF.10 – 2D → DXF.12 – 3D	→ MicroStation → Minicad 7.0	→ Velum 2.7 → Velum 4.0	→ Iges 5	→ MBA_CAD Part 1	→ MBA_SIM Part 1
← Hammer Tenons	H_001	→ DXF.10 – 2D → DXF.12 – 3D	→ MicroStation → Minicad 7.0	→ Velum 2.7 → Velum 4.0	→ Iges 5	→ MBA_CAD Part 1 → MBA_CAD Part 2	→ MBA_SIM Part 1 → MBA_SIM Part 2
← Lapped Hammer Tenons	H_002	→ DXF.10 – 2D → DXF.12 – 3D	→ MicroStation → Minicad 7.0	→ Velum 2.7 → Velum 4.0	→ Iges 5	→ MBA_CAD Part 1 → MBA_CAD Part 2	→ MBA_SIM Part 1 → MBA_SIM Part 2

